

CS19541-COMPUTER NETWORKS-LAB MANUAL

Practical 14

AIM: - Write a code using RAW sockets to implement packet sniffing.

Algorithm:

```
from scapy.all import sniff  
from scapy.layers.inet import IP, TCP, UDP, ICMP
```

```
def packet_callback(packet):
```

```
    if IP in packet:
```

```
        ip_layer = packet[IP]
```

```
        protocol = ip_layer.proto
```

```
        src_ip = ip_layer.src
```

```
        dst_ip = ip_layer.dst
```

```
# Determine the protocol name from protocol number
```

```
if protocol == 1:
```

```
    protocol_name = "ICMP"
```

```
elif protocol == 6:
```

```
    protocol_name = "TCP"
```

```
elif protocol == 17:
```

```
    protocol_name = "UDP"
```

```
else:
```

```
    protocol_name = "Unknown Protocol"
```

```
# Print packet details
```

```
print(f"Protocol: {protocol_name}")
```

```
print(f"Source IP: {src_ip}")
```

```
print(f"Destination IP: {dst_ip}")
```

```
print('-' * 30)
```

```
# Start packet capture on the default interface
```

```
sniff(prn=packet_callback, filter="ip")
```

CS19541-COMPUTER NETWORKS-LAB MANUAL

Practical 14

Output:-

Protocol: TCP

Source IP: 192.168.1.5

Destination IP: 172.217.26.206

Protocol: ICMP

Source IP: 192.168.1.5

Destination IP: 8.8.8.8

Protocol: UDP

Source IP: 192.168.1.5

Destination IP: 224.0.0.251

Protocol: TCP

Source IP: 172.217.26.206

Destination IP: 192.168.1.5

CS19541-COMPUTER NETWORKS-LAB MANUAL
